Jackson Racing Performance Parts Dual Stage Air Filter Part# 901-975

ALL APPLICATIONS:

ABOUT THE AIR FILTER

This filter is capable of filtering inlet air better than any other filter available. Due to its unique dual stage design, the first stage acting as a pre-filter catching and stopping larger debris and the final stage finishing the process by stopping dust size particles.

INSTALLING

The Jackson Racing DUAL STAGE air filters designed to replace the stock type element. When installing, the black side of the element will face the inlet air.

MAINTENANCE

This air filter is made of material that will last the lifetime of your car. Proper cleaning and oiling is very important for both engine performance and filter life.

1) Filter should be inspected every 5000 miles and cleaned at a max of 15,000 miles.

2) Cleaning the filter can be done with mild liquid soap or Jackson Racing filter cleaner and warm water.

3) After the filter has completely dried, oiling is required. Use foam air filter oil or Jackson Racing air filter oil for the ultimate in performance.

